

**ESTEAM CLEANING SYSTEMS**

# **DEFENDER 200 MODELS**

## **OWNER'S MANUAL**

Congratulations on your selection of a new Defender portable carpet cleaner built in Canada by Esteam Cleaning Systems. Our goal is to produce the best, high performance line of carpet cleaning equipment on the market today. Reading your Owner's Manual will help to achieve maximum benefit from your purchase.



# DEFENDER 200 Operating Manual

## TABLE OF CONTENTS

<b><u>TOPIC</u></b>	<b><u>PAGE #</u></b>
• Introduction	3
• Technical Specifications	4
• Safety	5
• Operations	7
• Maintenance	9
• Optional Equipment	10
• Trouble Shooting	11
<b><u>Technical</u></b>	
• Warranty	14
• Defender 200 Drawings & Parts Lists	18
• Defender 200 With Heat Drawings & Parts Lists	30
• Internal Heatermate	42
• Defender 200 2 – 3 Stage Drawings & Parts List	44
• 200PSI Pump Drawings & Parts List	56

# Introduction

Congratulations on your purchase of the Defender 200. The Defender 200 is designed to give truckmount-level performance in a portable machine that combines versatility with ease of transport. Years of experience, engineering, and planning have gone into the design and manufacturing of the Defender 200. We take great pride in our equipment; our goal is no less than your complete satisfaction.

## **The Defender 200 is intended for commercial use only.**

This manual will provide users with the knowledge required to operate the Defender 200 safely, to understand how to properly operate and maintain the machine, and to ensure that the equipment operates at its maximum performance level.



**All users must read and understand this manual completely before operating the machine.**

Always maintain this manual in legible condition adjacent to the Defender 200, or place it in a secure location for future reference.

Any questions pertaining to the operating or servicing of this unit should be directed to your nearest Esteam distributor.

This manual is written specifically for the Defender 200 portable extractor units manufactured by Esteam Manufacturing.

Information in this manual is subject to change without notice and does not represent a commitment on the part of Esteam Mfg., or its parent or affiliated companies.

# Technical Specifications

	<b>Defender 200 Defender 200-20</b>	<b>Defender 200-05 Defender 200-20-05</b>	<b>Defender 200-10 Defender 200-20-10</b>
<b>ELECTRICAL</b> Amps Volts	One cord 115 amps 115 volts or 220 volts	Two cords 15 amps per cord 115 volts or 220 volts	Two cords 15 amps per cord 115 volts or 220 volts
<b>VACUUM MOTOR</b> Cfm's Vacuum lift	2-2 stage 94 150"	2-3 stage High Performance 101 185"	2-2 stage 94 150"
<b>PUMP</b>	200 PSI Diaphragm	200 PSI Diaphragm	200 PSI Diaphragm
<b>INTERNAL HEATER</b>	N/A	N/A	1850 watt / 200°F
<b>SOLUTION TANK</b> (Clean water)	12 gallons (45 litres)	12 gallons (45 litres)	12 gallons (45 litres)
<b>RECOVERY TANK</b>	12 gallons (45 litres)	12 gallons (45 litres)	12 gallons (45 litres)
<b>LENGTH</b>	34 inches (86 cm)	34 inches (86 cm)	34 inches (86 cm)
<b>WIDTH</b>	23 inches (58 cm)	23 inches (58 cm)	23 inches (58 cm)
<b>HEIGHT</b>	42 inches (106 cm)	42 inches (106 cm)	42 inches (106 cm)
<b>WEIGHT</b>	117 lbs (53.07 kgs)	122 lbs (55.34 kgs)	127 lbs (57.61 kgs)

# Safety


## WARNING

This machine is an electrical appliance.

Care must be taken to reduce the risk of electrical shock.

**READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE OPERATING THE DEFENDER 200.**

- To reduce the risk of property damage or injury, repairs to electrical systems should only be performed by experienced technicians. Contact your distributor for assistance. Unplug machine power cord from outlet before performing any repairs on the extractor.
- This machine shall be grounded while in use to protect the operator from electric shock. The machine is provided with a three-conductor cord and a three-contact grounding type attachment plug to fit the proper grounding type receptacle. The green (or green and yellow) conductor in the cord is the grounding wire. Never connect this wire to other than the grounding pin of the attachment plug.
- This machine is for use on a nominal 120-volt circuit and has a grounding plug that resembles the plug illustrated in the sketch to the right. Make sure that the machine is connected to an outlet having the same configuration as the plug. No plug adapter should be used with this machine.
- The power cords supplied with this machine are properly sized to handle the electrical load of this machine and properly grounded as described above. Any extension cords used with this machine must be similarly sized with an equal or greater load rating and grounded to assure safe operation. A properly sized or rated GFCI protected cord can be used for additional protection.
- The two power cords must be plugged into separate circuits during operation.
- Do not use the DEFENDER 200 outdoors, in standing water or on wet surfaces. Do not store the DEFENDER 200 in wet conditions. If extractor is leaking, unplug machine power cords from outlets before approaching or touching machine.



- Do not unplug power cord by pulling on the cord. Grasp the plug end when unplugging the cord. Do not pull the extractor by the cord. If cord or plug is damaged, do not use cord. Replace with new cord or repair as needed before use.
- Overloaded circuit may not always trip circuit breaker. Reduced voltage to a machine on an overloaded circuit will prevent components from operating properly.

## NOTICE

This machine must be protected from conditions which may damage the pump, tank, hoses and other components.

- **Freezing of water in this machine will cause serious damage.** The Defender 200, solution hoses, and tools must be protected from freezing temperature. Store, transport, and use this equipment only in temperatures well above freezing. (32°F or 0°C). If you suspect the Defender 200 has been frozen, do not plug in or turn on machine until you are sure it has thawed completely.

- If the equipment cannot be stored or transported in a warm environment, it can be guarded from freezing by running an anti-freeze solution through the incoming water lines, solution pump, solution lines, tools.
  - The anti-freeze solution must be completely flushed from the machine before it is returned to service.
- The Defender 200 must not be used to pick up flammable or combustible materials or used in areas where these materials may be present.
- Solvent-based or water-based solutions containing solvents may damage the pump, hoses, and other components. Do not assume chemical compatibility. Contact your distributor or Esteam Mfg if you have questions regarding the compatibility of your chemicals with the machine.
- Do not clean with solutions that are at temperatures above 130°F.
- Rinse the solution tank, chemical system, and pump with fresh water after each day's use.
- Do not allow pump to run dry. Always maintain adequate solution level to supply solution pump.
- HP hoses may rupture if worn or damaged. Do not use HP solution hoses if hose covering is cut, bulging, or otherwise damaged. Examine HP solution hoses daily and replace or repair hoses as needed.
- Use a Hydro-Filter II and clean the recovery tank daily to keep pump-out filter and pump from becoming clogged. Store the Defender 200 with the recovery tank lid open.
- Keep Vacuum Inlet Filter clean and check float for proper operation. Do not operate the Defender 200 without the Vacuum Inlet Filter in place. **Use defoamer to eliminate foam build-up during cleaning and prevent foam/moisture from entering vacuums.**

## **WARNING**

**Use common sense to protect yourself and others while using this equipment.**

- Keep pets and children away from the machine when in use.
- Keep all body parts, hair, and loose clothing away from openings and moving parts. Always wear appropriate work clothing and safety equipment when operating unit.
- Use extra care when cleaning on stairs. Wet carpet on stairs can be slippery.
- Do not move the DEFENDER 200 up or down stairs when tanks are full of water. Drain solution and recovery tanks, and secure base latches before moving unit up or down stairs. Lift using only the machine handles designed & designated for moving and lifting.
- Water may be spilled, drip, or be exhausted from vacuums during operation. Place unit in area where water will not cause damage or use drop cloth to protect surfaces.

# Operation Procedures

*Knowledge of the proper operation of the Defender 200 is required to ensure user safety and efficient performance of the extractor.*

## SET UP AND OPERATION

1. Insert electrical cords into 3 pin grounded outlets. Two cord machines maybe equipped with the **Optional** Circuit Indicator located above the Switch Plate. The electrical cords must be plugged into separate circuits. When this is achieved the green light will illuminate showing the machine is ready for operation.
2. We recommend the use of a Esteam liquid Defoamer, to prevent the machine from prematurely shutting off due to excess foam in the recovery tank. Turn on vacuum and pour approximately  $\frac{1}{4}$  cup of Esteam Liquid Defoamer into the end of the vacuum hose.
3. **200 PSI Plunger pump priming instructions:**
  - Fill freshwater tank
  - Turn on vacuum
  - Always release the pressure by depressing the prime valve prior to turning on the pump, to release head pressure and prevent blowing fuse or over amping the pump motor
  - Turn on pump
  - Cover vacuum barb on recovery tank
  - Pull prime valve trigger for about 30 seconds
  - Shut off pump and vacuum
  - Connect hoses for cleaning and machine is ready to use.

## TO USE YOUR DEFENDER HEATER:

- A. Hook the wand solution hose to the quick connect of your machine.
- B. Plug the heater power cord into a wall that is on a separate circuit from the other cord.
- C. Turn the heater switch on.
- D. When the red light goes out, the solution is heated and ready to use.

## OPERATING INSTRUCTIONS (CONTINUED)

**WARNING:** If your heater does not work DO NOT attempt to repair it yourself, call your distributor for repair procedures. Using solvents in heaters can be hazardous and will void your warranty. Allowing heaters to freeze will crack the heater cartridge and will also void your warranty.

**DANGER:** No solvents of any type may be used in this system at any time. The use of solvents is extremely hazardous resulting in possible fire and/or explosion.

4. Connect vacuum and solution hoses to the carpet cleaning wand.
5. Proceed to clean carpets.
6. When the recovery tank becomes full, vacuum will automatically stop extracting.

When vacuum stops extracting it will make a distinctive high pitched noise as all the air flow will be cut off. At this time switch unit off. Drain the recovery tank by pulling up on drain valve on front of machine

**NOTE:** Ensure that the high-water level float screen inside the recovery tank is free from any obstructions. Be sure to close drain valve before resuming cleaning.

7. To empty solution tank remove vacuum hose from wand. Turn on vacuum and extract solution from solution tank into recovery tank, then drain recovery tank.

**NOTE:** Do not completely submerge the end of vacuum hose into solution. Allow some air to enter end of vacuum hose with liquid.

8. When the job is completed, empty and rinse out the solution and recovery tanks. Allow vacuum to run for 3 to 5 minutes. This will eliminate all moisture from vacuum assuring long vacuum life.

**WARNING:** When using electrical equipment around water it is important to wear rubber soled shoes and keep machine properly grounded at all times. Failure to do so could result in electric shock.

## MAINTENANCE

### DAILY:

- Clean high water level float screen inside the recovery tank.
- Ensure high level float ball is working properly.
- Rinse out recovery tank after use.
- Clean dirt and obstructions from the (recovery tank) drain valve rubber gaskets to prevent premature wear.
- Rinse out pump with clean water at conclusion of workday.
- Clean poly housing with mild soap and water.

### MONTHLY:

- Clean air inlet and check exhaust port.
- Check 1 ½ dump valve seal.

### YEARLY:

- We recommend that your unit be inspected by a qualified service technician once a year.

### PREVENTATIVE MAINTENANCE:

- Never store this unit in a place where there is a possibility of the temperature dropping below 0°C (32°F)

## Accessory Storage Options:

The Defender 200 is designed to make it easier for the operator to transport the machine and the most common cleaning accessories.

### Bucket & Sprayer Storage

The top of the Defender 200 is sized and recessed to hold a five-gallon bucket or two one-gallon chemical bottles as well as two 2QT sprayers.

### Power Cord Storage

The back of the Defender 200 has two sets of cord wraps to hold two 12/3 x 25' power cords.

### Carpet Wand Storage

The front of the Defender 200 is designed to hold a S-Bend Carpet wand and has two straps to hold it securely. Optional strap for larger wands available

### Other Tool & Hose Storage

Each side of the Defender 200 has a set of molded in threaded inserts to which holders can be attached to hold other accessories or supplies making it much easier to move around. Four 1/4-20 x 5/8" mounting screws are required.



## TROUBLE SHOOTING

**WARNING:** Prior to inspection or repair of this machine, disconnect all electrical cords rendering the machine powerless. Failure to do so could result in serious or fatal injury.

PROBLEM	CAUSE	SOLUTION
1. Entire unit will not operate	1. Unit not plugged in 2. Loose wiring	1. Connect unit to 3 pin grounded outlets 2. See dealer
2. Pump will not run	1. Switch not turned on 2. Broken switch 3. Loose wiring 4. Pump motor defective	1. Turn on switch 2. See dealer 3. See dealer 4. See dealer
3. Vacuum will not run	1. Switch not turned on 2. Broken switch 3. Loose wiring 5. Blocked rotor	1. Turn on switch 2. See dealer 3. See dealer 5. See dealer
4. Pump runs but does not pump solution	1. Out of solution 2. Pump inlet screen plugged 3. Pump was not properly primed 4. Kink in solution hose 5. Plugged jet or quick connect 6. Internal (inside machine) or external solution line damaged and leaking	1. Fill solution 2. Clean inlet screen 3. Prime pump using priming hose 4. Remove kink 5. Remove blockage 6. See dealer

## TROUBLE SHOOTING (CONTINUED)

<b>PROBLEM</b>	<b>CAUSE</b>	<b>SOLUTION</b>
5. Pump runs but has loss pressure	1. Partial kink in solution hose 2. Partial blockage in solution hose 3. Jet orifice opening on cleaning wand is too large 4. Internal pump components wearing out	1. Remove kink 2. Remove blockage 3. Total jet opening for 200 PSI pump should be .06 or .08. Heat option should be .03 4. See dealer
6. Vacuum operates but has poor or no suction	1. Recovery tank full 2. Vacuum hose plugged 3. Wand plugged 4. Exhaust port blocked 5. High level float stuck in off position 6. Front drain valve left open after draining recovery tank	1. Drain recovery tank 2. Locate and remove blockage 3. Locate and remove blockage 4. Locate and remove blockage 5. Turn vacuum off and tap top of float screen cage 6. Close recovery tank drain valve on front of machine
7. Vacuum prematurely stops extracting	1. Excess foam in recovery tank 2. Lint or dirt on automatic shut off float screen 3. Defective float ball	1. Add defoamer to recovery tank 2. Clean auto shut off float screen 3. Replace float screen cage

## TROUBLE SHOOTING (CONTINUED)

**PROBLEM**

8. Machine spits water out of exhaust port

**CAUSE**

1. High level float not working properly

**SOLUTION**

1. Check auto shut off float cage and ball for proper operation

9. Machine blowing excessive amounts of water out of exhaust ports

1. Damaged (leaking) recovery tank fittings

1. Immediately shut unit down. Bring unit to a dealer for service

10. Water accumulating in bottom electrical component area

1. Inside solution line leaking

1. Immediately shut unit down. Bring unit to a dealer for service

2. Pump leaking

2. Immediately shut unit down. Bring unit to a dealer for service

3. Solution or recovery tank leaking from above

3. Immediately shut unit down. Bring to a dealer for service

11. Heater won't work.

1. Heater cord not plugged in.

Connect cord to 3 Pin (Separate) outlet

2. Faulty Thermostat or Thermo cut-out

See dealer

12. Water not hot enough

1. Check Jet size on wand or upholstery tool. Do not exceed .03 orifice size for maximum heat transfer

2. Do not use cold water in solution tank. Must use hot tap water for maximum heat transfer

# **ESTEAM CLEANING SYSTEMS**

## **Portable Extractor Warranty**

## **DEFENDER**

**NOTICE: REVIEW THIS WARRANTY CAREFULLY AS THIS DOCUMENT CONTAINS LIMITATION AND EXCLUSIONS.**

### **PART I:**

Esteam Manufacturing (hereinafter referred to as "Esteam") warrants each new Esteam Portable Extractor, to the original purchaser only, subject to the limitations as defined in the specific details of its warranty coverage defined below.

#### **HOUSING WARRANTY COVERAGE**

Esteam warrants the portable extractor Polyethylene Machine Housing Unit to be free from defects in material and workmanship (including cracking, leaking, or deterioration) for 24 months, expressly subject to the limitations stated herein.

In the event a defect occurs in the portable extractor housing within 24 months of receipt by the original customer, Esteam will, if satisfied on its examination that the failure is due to defective material or workmanship, repair or replace the portable extractor housing unit, base, solution tank, recovery tank, at no cost to the original customer, other than as maybe provided for in this warranty.

#### **PART II - REPLACEMENT PARTS (UNDER WARRANTY)**

Replacement warranty parts will be genuine Esteam parts, or parts of similar kind and quality.

All replacement warranty parts are warranted to be free from defects in materials or workmanship from the date of the original unit purchase for the balance of the original warranty. Parts replaced after warranty expiration are covered for 30 days.

#### **PART III - LIMITATIONS ON WARRANTY COVERAGE**

##### **WHAT IS NOT COVERED:**

Notwithstanding any other term or covenant of Esteam contained herein, the following provisions shall apply:

- (i) No warranty is provided for any Esteam product which has failed as a result of freezing, fire, misuse, alteration, improper amps or voltage, accidental damage, improper maintenance, unauthorized repairs, alterations, abuse, neglect or operation of a Esteam product not expressly recommended or contemplated by Esteam; and
- (ii) No warranty is provided for mechanical or electrical breakdown caused by scale, hard water buildup, improper use of chemicals or resins, damage due to environmental conditions, and acts of God, or other events beyond the control of Esteam; and

- (iii) No warranty is provided for mechanical or electrical breakdown or failure of an Esteam product resulting from ordinary wear and tear, or the consequences thereof; including but not limited to the gradual reduction of the operating performance of the product. The determination of what is or is not ordinary wear and tear is at the sole discretion of Esteam; and
- (iv) No warranty is provided for damage caused by the failure of non-warranted parts and/or accessories, even if warranted parts are damaged as a result of the failure of a non-warranted part; and
- (v) No warranty is provided for damage resulting from failure by the customer to maintain scheduled maintenance requirements. The Esteam system has many parts which must either be replaced or checked for wear on a regular basis; including but not limited to replacement filters and lubricants. This system requires regular maintenance, service and attention by the customer; and
- (vi) No warranty is provided as to any extra expenses incurred by the customer, including but not limited to economic, incidental, consequential loss or damage (e.g. all labour charges, rental equipment, down time, lodging, commercial or business loss of any nature or kind due to product failure); whether direct or indirect, exemplary or punitive damage or loss, and whether in contract, tort or otherwise; and
- (vii) No warranty is provided as to failure of any cosmetic item or finish, labeling, silk screening, decals, paint, trim or other similar decorative items.
- (viii) Brass, rubber and synthetic rubber parts (e.g. "O" rings, diaphragms, gaskets, seals, grommets) are considered expendable in normal use, and are therefore not included in any warranty by Esteam.

#### **PART IV - EXCLUSION OF LIABILITY**

Esteam makes no warranties or representations, either expressed or implied, oral or written, in fact, or by operation of law, or otherwise, except as expressly stated herein warranties. Esteam, its officers, directors, agents, dealers and its affiliates (and their respective officers, directors, agents and dealers) shall not be liable to the customer nor to any party for any

liability, including without limitation, strict liability, liability for loss, injury or damage due directly or indirectly to the use or operation of the Esteam product; consequential, exemplary and/or punitive damage or loss, whether in contract, tort, or otherwise.

#### **PART V - RETURN GUIDELINES**

Defective items must be replaced through a local Esteam Distributor. Replacement parts will be sent via prepaid regular ground service to the distributor. The defective part must be returned F.O.B. factory within 30 days including a letter providing the machine's serial number, date of purchase, material return authorization number, and customer name. If applicable, credit will be issued after the item has been evaluated by Esteam. Failure to comply with return policy will void the warranty on that item.

## **PART VI - CREDIT POLICY**

All customers purchasing parts through an Esteam distributor must arrange credit directly with that distributor.

## **PART VII - OUTSIDE SOURCE WARRANTY REPAIRS**

At the sole discretion of Esteam, it may be necessary to perform warranty/repairs at an outside source. An estimate must be submitted to and approved by Esteam prior to work being performed. Failure to do so will result in denial of your warranty claim.

**This warranty is not transferable to any subsequent owner.**

## **PART IX - NOTICE - CUSTOMER OBLIGATIONS**

(i) Your responsibility as a customer includes but is not limited to cleaning, lubricating, seasonal maintenance (e.g. winterizing), replacement of worn parts and all regular scheduled or unscheduled maintenance.

(ii) Any claim for warranty must be presented to Esteam or its authorized dealer, prior to the expiration of the time limitations specified and not thereafter, otherwise any warranty is void.

(iii) Notwithstanding the generality of the foregoing customer obligations, Esteam does hereby bring to the attention of the customer, these specific maintenance operating requirements of the Portable Extractors to validate its warranty:

### **(a) Chemical Warning:**

Any improper use of chemicals shall void any Esteam warranty and thusly exclude any liability by Esteam. No dry cleaning chemical may be used in an Esteam Portable Extractor; - as any such use may result in fire or pump/motor damage. A defoamer solution must be used by customer to limit foaming in the recovery tank.

### **(b) Vacuum Motors:**

Require use of a defoamer. A vacuum motor showing moisture contamination on interior components shall void any warranty by Esteam.

### **(c) Pumps:**

All pumps require daily flushing with clean water after use.

### **(d) Internal Heatermate:**

The internal heater must be flushed with clean water after every use. Any buildup of hard water deposits or chemical build up within the internal heater will void any Esteam warranty thusly exclude any liability of Esteam.

The foregoing constitutes Esteam's entire warranty and no other warranty, liability, contingency or responsibility, direct, indirect, consequential or in any other way connected with the sale or operation of Esteam machines or chemical product is expressed or implied.


WARRNATY REFERENCE CHART

Polyethylene Base Housing	24 Months
Polyethylene Solution Tank Housing	24 Months
Polyethylene Recovery tank Housing	24 Months
All electrical, wiring, switches, fuses, cords, gaskets	90 Days
Vacuum Motors (See Conditions)	12 Months
Pump (See Conditions)	12 Months
Pump Internal Parts Valves, Diaphragms, O-rings,	No warranty wearable parts
Internal Hoses	90 Days
External Vacuum & Solution Hoses	30 Days
Wheels	12 Months
Quick Connects	90 Days
Dump Valve	90 Days
Pressure Regulator & Prime Valves	12 Months
Gauges	90 Days
Labor	90 Days

You must register your warranty online to activate your warranty.

Go to [www.esteam.com](http://www.esteam.com) then click on Warranty Enrollment and complete the Warranty Enrollment Form and click on submit.


# Defender 200



# Defender 200

REF	PART NO.	DESCRIPTION	NOTES
1	555-325	HOSE BARB 90, 1/2 BARB X 1/4 MPT	
2	555-182	ELBOW 45, 1/4" FEM. EXTRUDED	
3	555-073	CLOSE NIPPLE, 1/4 SS	
4	530-025	REGULATOR, 500 PSI	
5	555-452	PLUG, 1/4 MPT HEX	
6	305-015	FILL PLUG, PANEL	
7	305-085	SWITCH, ROCKER - WHITE	
8	580-010	Q.C. 1/4" FEM (CLOSED)	
9	590-425	PVC HOSE BARB, 1 1/2""HB X 2"MPT	
10	595-005	ABS PIPE, 1 1/2"	
11	410-415	CS, 1/4 X 20 X 1/2 SS SOC	
12	415-125	FW, 1/4 SS	
13	845-050	CONTROL PANEL. DEFENDER	
14	415-156	FW,1/2 MILITARY 18.8 MS-819	
15	555-184	ELBOW 45, STREET 1/4"	
16	590-010	PVC ELBOW 1 1/4" 90, S x S	
17	345-005	FUSE HOLDER PANEL	
18	498-055	PLUG, 1/2" NYLON	


# Defender 200



# Defender 200

REF	PART NO.	DESCRIPTION	NOTES
1	410-160	MS, 10-24 X 3/4 PAN PH SS	
2	585-220	LID ASSY 8"	
3	400-039	NUT, 10-24 K-LOK	
4	410-265	MS, 5/16 X 2 1/2 PAN PHIL SS	
5	415-128	FW, 5/16 SS	
6	355-230	VAC SPACER, 1 1/8"	
7	455-070	WHEEL, 3" DIA CUSHION RUBBER	
8	400-116	LOCKNUT, 5/16 x 18 NYLON SS	


# Defender 200



# Defender 200

REF	PART NO.	DISCRIPTION	NOTES
1	588-020	ABS ELBOW 45, 1 1/2" SLP X SLP	
2	545-100	.DUMP VALVE, 1 1/2" (FLANGE-MPT)	
3	465-075	POWER CORD , BRACKET	
4	415-125	FW, 1/4 SS	
5	410-410	CS, 1/4-20 X 3/4 SOC S/S	
6	335-015	STRAIN RELIEF, 14 GAUGE	
7	315-015	CORD, 25' BLACK 14/3 SJTW-A	
8	335-015	STRAIN RELIEF, 14 GAUGE	
9	410-205	MS, 10-32 X 1/2 PANPHIL SS	
10	560-325	GUARD, FINGER - 4" MUFFIN FAN	
11	400-043	NUT, 10-32 KEPS LOCKNUT	
12	400-165	LOCKNUT, 1/2" STEEL / STRAIN RELIEF	


# Defender 200



# Defender 200

REF	PART NO.	DISCRIPTION	NOTES
1	415-120	FW, 1/4 ZINC	
2	405-620	BOLT, 1/4X3/4 SS(HEX HD)	
3	455-006	CASTER, 5" SWIVEL	
4	410-205	MS, 10-32 X 1/2 PANPHIL SS	
5	445-012	LATCH	
5A	445-013	KEEPER	Not Shown
6	400-135	LOCKNUT, 1/4 X 20 NYLON ZINC	
7	845-095	PLATE, BASE, DEFENDER	
8	470-065	AXLE, DEFENDER	
9	455-060	WHEEL, 10"	
10	455-052	WHEEL CAP DOME - 1/2" METAL	
11	385-050	COLLAR, 1/2" SHAFT - HM	
12	440-020	HINGE, DEFENDER, PAIR	


# Defender 200



# Defender 200

REF	PART NO.	DESCRIPTION	NOTES
1	597-010	FLOAT SCREEN CAGE - 1 1/2	
2	597-061	ADPT (RM) 30 DEGREE, FLOAT SCREEN 1 1/2"	
3	595-005	ABS PIPE, 1 1/2"	
4	590-415	PVC ADPT 1 1/2", S x MPT	
5	590-205	PVC WALL FITTING, 1 1/2"	
6	590-405	PVC HOSE BARB 1 1/2" x MPT	


# Defender 200



# Defender 200

REF	PART NO.	DESCRIPTION	NOTES
1	572-155	POLYSPRING HOSE, 1/2"	
2	570-010	VAC HOSE, 1 1/2" WIRE REINFORCED	
3	355-451	VACUUM MOTOR 2 STAGE (AMETEK) w/adapter	
4	405-065	BOLT, 1/4 X 6 RH STOVE ZINC(ALL THREAD)	
5	415-120	FW, 1/4 ZINC	
6	400-135	LOCKNUT, 1/4 X 20 NYLON ZINC	
7	572-041	L.P. HOSE 3/8 BLUE	
8	590-010	PVC ELBOW 1 1/4" 90, S x S	
9	595-004	ABS PIPE, 1 1/4"	
10	572-125	PULSE HOSE, 3/8"	
11	581-065	CRIMP FTNG, 3/8" PULSE HOSE 1/4 MPT SVL	
12	555-208	ELBOW 90, 1/4" STREET EXTRUDED	
13	555-206	ELBOW 90, 1/4" FPT. EXTRUDED	
14	512-500	PUMP,200 PSI MODEL 112V	
15	512-510	MOTOR, 200 PSI LEESON M70	
15A	512-505	PUMP,200 PSI-112V-V & LEESON MOTOR M70	#14 & #15 COMBINED


# Defender 200 With Heat



# Defender 200 With Heat

REF	PART NO.	DESCRIPTION	NOTES
1	555-325	HOSE BARB 90, 1/2 BARB X 1/4 MPT	
2	415-125	FW, 1/4 SS	
3	410-415	CS, 1/4 X 20 X 1/2 SS SOC	
4	555-182	ELBOW 45, 1/4" FEM. EXTRUDED	
5	555-073	CLOSE NIPPLE, 1/4 SS	
6	530-025	REGULATOR, 500 PSI	
7	555-452	PLUG, 1/4 MPT HEX	
8	305-085	SWITCH, ROCKER - WHITE	
9	580-010	Q.C. 1/4" FEM (CLOSED)	
10	590-425	PVC HOSE BARB, 1 1/2""HB X 2" MPT	
11	595-005	ABS PIPE, 1 1/2"	
12	845-050	CONTROL PANEL. DEFENDER	
13	415-156	FW, 1/2 MILITARY 18.8 MS-819	
14	555-184	ELBOW 45, STREET 1/4"	
15	590-010	PVC ELBOW 1 1/4" 90, S x S	
16	345-005	FUSE HOLDER PANEL	
17	320-110	LAMP, PANEL(RED) 110V	
18	498-081	PLUG, 2 1/2" NYLON	


# Defender 200 With Heat



# Defender 200 With Heat

REF	PART NO.	DESCRIPTION	NOTES
1	410-160	MS, 10-24 X 3/4 PAN PH SS	
2	585-220	LID ASSY 8"	
3	400-039	NUT, 10-24 K-LOK	
4	410-265	MS, 5/16 X 2 1/2 PAN PHIL SS	
5	415-128	FW, 5/16 SS	
6	355-230	VAC SPACER, 1 1/8"	
7	455-070	WHEEL, 3" DIA CUSHION RUBBER	
8	400-116	LOCKNUT, 5/16 x 18 NYLON SS	


# Defender 200 With Heat



# Defender 200 With Heat

REF	PART NO.	DISCRIPTION	NOTES
1	588-020	ABS ELBOW 45, 1 1/2" SLP X SLP	
2	545-100	.DUMP VALVE, 1 1/2" (FLANGE-MPT)	
3	465-075	POWER CORD , BRACKET	
4	415-125	FW, 1/4 SS	
5	410-410	CS, 1/4-20 X 3/4 SOC S/S	
6	335-015	STRAIN RELIEF, 14 GAUGE	
7	315-015	CORD, 25' BLACK 14/3 SJTW-A	
8	335-015	STRAIN RELIEF, 14 GAUGE	
9	410-205	MS, 10-32 X 1/2 PANPHIL SS	
10	560-325	GUARD, FINGER - 4" MUFFIN FAN	
11	400-043	NUT, 10-32 KEPS LOCKNUT	
12	400-165	LOCKNUT, 1/2" STEEL / STRAIN RELIEF	


# Defender 200 With Heat



# Defender 200 With Heat

REF	PART NO.	DESCRIPTION	NOTES
1	415-120	FW, 1/4 ZINC	
2	405-620	BOLT, 1/4X3/4 SS(HEX HD)	
3	455-006	CASTER, 5" SWIVEL	
4	410-205	MS, 10-32 X 1/2 PANPHIL SS	
5	445-012	LATCH	
5A	445-013	KEEPER	Not Shown
6	400-135	LOCKNUT, 1/4 X 20 NYLON ZINC	
7	845-095	PLATE, BASE, DEFENDER	
8	470-065	AXLE, DEFENDER	
9	455-060	WHEEL, 10"	
10	455-052	WHEEL CAP DOME - 1/2" METAL	
11	385-050	COLLAR, 1/2" SHAFT - HM	
12	440-020	HINGE, DEFENDER, PAIR	


# Defender 200 With Heat



# Defender 200 With Heat

REF	PART NO.	DESCRIPTION	NOTES
1	597-010	FLOAT SCREEN CAGE - 1 1/2"	
2	597-061	ADPT (RM) 30 DEGREE, FLOAT SCREEN 1 1/2"	
3	595-005	ABS PIPE, 1 1/2"	
4	590-415	PVC ADPT 1 1/2", S x MPT	
5	590-205	PVC WALL FITTING, 1 1/2"	
6	590-405	PVC HOSE BARB 1 1/2" x MPT	


# Defender 200 With Heat



# Defender 200 With Heat

REF	PART NO.	DESCRIPTION	NOTES
1	570-010	VAC HOSE, 1 1/2" WIRE REINFORCED	
2	572-125	PULSE HOSE, 3/8"	
3	355-451	VACUUM MOTOR 2 STAGE (AMETEK) w/adapter	
4	400-135	LOCKNUT, 1/4 X 20 NYLON ZINC	
5	415-120	FW, 1/4 ZINC	
6	405-065	BOLT, 1/4 X 6 RH STOVE ZINC(ALL THREAD)	
7	555-003	ADAPTOR, SS, 1/4 X 1/4	
8	490-005	FOAMED CASING, ROUND 1850W - HM	
9	590-010	PVC ELBOW 1 1/4" 90, S x S	
10	572-041	L.P. HOSE 3/8 BLUE	
11	555-208	ELBOW 90, 1/4" STREET EXTRUDED	
12	572-155	POLYSRINT HOSE, 1/2"	
13	581-065	CRIMP FTNG, 3/8" PULSE HOSE 1/4 MPT SVL	
14	263-007	HP HOSE, 10 "-1/4 MPT SWV X 1/4 HOSE	
15	555-206	ELBOW 90, 1/4" FPT. EXTRUDED	
16	512-510	MOTOR, 200 PSI LEESON M70	
17	512-500	PUMP, 200 PSI MODEL 112V	
17A	512-505	PUMP, 200 PSI-112V-V & LEESON MOTOR M70	
18	555-452	PLUG, 1/4 MPT HEX	
19	263-007	HP HOSE, 10 "-1/4 MPT SWV X 1/4 HOSE	
20	263-012	HP HOSE, 48" x 1/4" SWV X 1/4" HOSE	


### INTERNAL HEATER MATE



## **INTERNAL HEATER MATE (490-005/490-006)**

REF	PART NO.	DESCRIPTION	NOTES:
1	305-245	Thermo Cut-Out	
2	305-265	Thermostat 200F	
3A	318-005	Heater Element 1850W 110V	Use For 490-005
3B	318-900	Heater Element 1850W 220V	Use For 490-006
4	325-005	Connector, Butt - Blue	
5	325-120	Spade, 3/16 F - Blue	
6	325-230	Terminal Ring, #10 - Blue	
7	325-500	Spade, 1/4 FEM. 90 Crimp	
8	330-225	Wire, 14 GA - Black	
9	330-230	Wire, 14 GA - Green	
10	330-235	Wire, 14 GA - White	
11	330-240	Wire, 14 GA - Yellow	
12	410-070	MS, 6 x 3/16 Pan PHL	
13	415-005	LW, 6 Zinc	
14	475-045	Gasket, 3" RND	Not Shown
15	475-070	Gasket 1/8"	Not shown
16	490-016	Alum (Round) Casing	
17	555-002	ADPT, 1/4 M x 1/4 F	
18	555-451	Plug, 1/8 Hex	


# Defender 200 2 – 3 Stage



# Defender 200 2 – 3 Stage

REF	PART NO.	DESCRIPTION	NOTES
1	555-325	HOSE BARB 90, 1/2 BARB X 1/4 MPT	
2	555-182	ELBOW 45, 1/4" FEM. EXTRUDED	
3	555-073	CLOSE NIPPLE, 1/4 SS	
4	530-025	REGULATOR, 500 PSI	
5	555-452	PLUG, 1/4 MPT HEX	
6	305-015	FILL PLUG, PANEL	
7	305-085	SWITCH, ROCKER - WHITE	
8	580-010	Q.C. 1/4" FEM (CLOSED)	
9	590-425	PVC HOSE BARB, 1 1/2""HB X 2"MPT	
10	595-005	ABS PIPE, 1 1/2"	
11	410-415	CS, 1/4 X 20 X 1/2 SS SOC	
12	415-125	FW, 1/4 SS	
13	845-050	CONTROL PANEL. DEFENDER	
14	415-156	FW,1/2 MILITARY 18.8 MS-819	
15	555-184	ELBOW 45, STREET 1/4"	
16	590-010	PVC ELBOW 1 1/4" 90, S x S	
17	345-005	FUSE HOLDER PANEL	
18	498-055	PLUG, 1/2" NYLON	


# Defender 200 2 – 3 Stage



# Defender 200 2 – 3 Stage

REF	PART NO.	DESCRIPTION	NOTES
1	410-160	MS, 10-24 X 3/4 PAN PH SS	
2	585-220	LID ASSY 8"	
3	400-039	NUT, 10-24 K-LOK	
4	410-265	MS, 5/16 X 2 1/2 PAN PHIL SS	
5	415-128	FW, 5/16 SS	
6	355-230	VAC SPACER, 1 1/8"	
7	455-070	WHEEL, 3" DIA CUSHION RUBBER	
8	400-116	LOCKNUT, 5/16 x 18 NYLON SS	


# Defender 200 2 – 3 Stage



# Defender 200 2 – 3 Stage

REF	PART NO.	DESCRIPTION	NOTES
1	588-020	ABS ELBOW 45, 1 1/2" SLP X SLP	
2	545-100	.DUMP VALVE, 1 1/2" (FLANGE-MPT)	
3	465-075	POWER CORD , BRACKET	
4	415-125	FW, 1/4 SS	
5	410-410	CS, 1/4-20 X 3/4 SOC S/S	
6	335-015	STRAIN RELIEF, 14 GAUGE	
7	315-015	CORD, 25' BLACK 14/3 SJTW-A	
8	335-015	STRAIN RELIEF, 14 GAUGE	
9	410-205	MS, 10-32 X 1/2 PANPHIL SS	
10	560-325	GUARD, FINGER - 4" MUFFIN FAN	
11	400-043	NUT, 10-32 KEPS LOCKNUT	
12	400-165	LOCKNUT, 1/2" STEEL / STRAIN RELIEF	


# Defender 200 2 – 3 Stage



# Defender 200 2 – 3 Stage

REF	PART NO.	DESCRIPTION	NOTES
1	415-120	FW, 1/4 ZINC	
2	405-620	BOLT, 1/4X3/4 SS(HEX HD)	
3	455-006	CASTER, 5" SWIVEL	
4	410-205	MS, 10-32 X 1/2 PANPHIL SS	
5	445-012	LATCH	
5A	445-013	KEEPER	Not Shown
6	400-135	LOCKNUT, 1/4 X 20 NYLON ZINC	
7	845-095	PLATE, BASE, DEFENDER	
8	470-065	AXLE, DEFENDER	
9	455-060	WHEEL, 10"	
10	455-052	WHEEL CAP DOME - 1/2" METAL	
11	385-050	COLLAR, 1/2" SHAFT - HM	
12	440-020	HINGE, DEFENDER, PAIR	


# Defender 200 2 – 3 Stage



# Defender 200 2 – 3 Stage

REF	PART NO.	DESCRIPTION	NOTES
1	597-010	FLOAT SCREEN CAGE - 1 1/2"	
2	597-061	ADPT (RM) 30 DEGREE, FLOAT SCREEN 1 1/2"	
3	595-005	ABS PIPE, 1 1/2"	
4	590-415	PVC ADPT 1 1/2", S x MPT	
5	590-205	PVC WALL FITTING, 1 1/2"	
6	590-405	PVC HOSE BARB 1 1/2" x MPT	

# Defender 200 2 – 3 Stage



# Defender 200 2 – 3 Stage

REF	PART NO.	DISCRIPTION	NOTES
1	355-551	VACUUM MOTOR 3 STAGE (AMETEK) w/adapter	
2	572-155	POLYSPRING HOSE, 1/2"	
3	572-125	PULSE HOSE, 3/8"	
4	570-010	VAC HOSE, 1 1/2" WIRE REINFORCED	
5	425-010	CLAMP, #20 HOSE 13/16 X 1 3/4	
6	585-110	NYLON 90 BARB 1/2 X 3/8 NPT	
7	590-010	PVC ELBOW 1 1/4" 90, S x S	
8	595-004	ABS PIPE, 1 1/4"	
9	511-105	ESTEAM PUMP, 150 PSI DIAPHRAM	
10	572-041	L.P. HOSE 3/8 BLUE	
11	585-110	NYLON 90 BARB 1/2 X 3/8 NPT	
12	555-208	ELBOW 90, 1/4" STREET EXTRUDED	
13	555-024	BUSHING, 3/8 M x 1/4 F	
14	415-120	FW, 1/4 ZINC	
15	400-135	LOCKNUT, 1/4 X 20 NYLON ZINC	
16	405-065	BOLT, 1/4 X 6 RH STOVE ZINC(ALL THREAD)	

## **PUMP 200 REPAIR KITS**

