

# NATURAL FIBRE PRESPRAY

## For Natural Fibres and Wool Carpets

NATURAL FIBRE PRESPRAY is a concentrated pre-conditioner for carpets or upholstery. The advanced formula is designed to gently lift the toughest soils from natural fibres.

- Dilution Ratio: 1:32
- Designed specifically for natural fibres
- Low foaming
- Specially formulated with surfactants and softening agents
- Powerful yet pH balanced Diluted pH: 7.5

Available in:

- 3.79 L (1 US Gallon) - Part # 2624-0301



**DIRECTIONS: Pump-up or Power Sprayer:** Mix 4 oz (118 ml) of Natural Fibre Prespray with 1 gal (3.79 L) of warm to hot water (1:32 Dilution). **Hydro-force™ Sprayer:** 4:1 Dilution (no tip): Mix 19¼ oz (572 ml) of Natural Fibre Prespray into a Hydro-force™ jug and fill with warm to hot water.

8:1 Dilution (yellow tip): Mix 35 oz (1.03 L) of Natural Fibre Prespray into a Hydro-force™ jug and fill with warm to hot water. For best results: Pile lift or vacuum carpets or upholstery prior to cleaning. Spray diluted Natural Fibre Prespray solution onto carpet or upholstery at a rate of approx. 800 - 1000 sq ft per gallon (3.78 L).

Agitate presprayed area using a horse hair upholstery brush or a carpet groomer. Allow 5 minutes dwell time, then rinse with Esteam Fibre Rinse solution in conjunction with hot water extraction. NOTE: Do not mix Esteam Natural Fibre Prespray with any other chemical product.

**Keep this product out of reach of children. Read the Safety Data Sheet and Product Label before using. Take the necessary precautions dictated by the label to ensure that your health and that of your customers' is protected.**

FOR SDS VISIT /POUR CONSULTER LES FDS VISITEZ LE: [www.esteem.com](http://www.esteem.com)

