



FIRE RESTORATION

Ceiling Cleaner is an easy to use two part cleaning system. It quickly cleans all types of acoustical and non-acoustical ceilings, as well as most wall surfaces.

- Safe on acoustical and non-acoustical surfaces
- Removes cigarette smoke and ceiling soils
- Easy to mix two part system
- Available in: 4 L (1.06 US gal.), or 20 L (5.28 US gal.)

EASILY REMOVE UNSIGHTLY YELLOWING AND SOILS FROM ACOUSTICAL AND NON-ACOUSTICAL CEILINGS



Dilution Ratio: Mix Part A with Part B

DIRECTIONS FOR USE:

Shake Part A well before using.

4 L (1.06 gal) Mixing: Mix one 4 L (1.06 gal) bottle of Ceiling Cleaner Part A with one 452 ml (15.3 oz) bottle of Ceiling Cleaner Part B to make a ready to use solution.

20 L (5.28 gal) Mixing: Mix one 20 L (5.28 gal) pail of Ceiling Cleaner Part A with five 452 ml (15.3 oz) bottles of Ceiling Cleaner Part B to make a ready to use solution.

Part A and Part B must be mixed at correct proportions to insure proper cleaning standards of mixed solution. Mixed solution becomes inactive within 8 hours after mixing. Although this product contains no bleach or strong oxidizing agents, and should

not harm carpets or drapes, it is good cleaning practice to cover all items in the area before application of mixed Ceiling Cleaner solution. Spray from 6-8 inches below ceiling using an electric sprayer in even, overlapping strips. 4L (1.06 gal) of mixed solution cleans approximately 800 - 1000 square feet.

To avoid eye contact and inhalation, wear eye protection and a respiratory filter while using this product.

NOTE: Do not mix Esteam Ceiling Cleaner Part A with any other chemical product other than Esteam Ceiling Cleaner Part B.

Keep this product out of reach of children. Read the Material Safety Data Sheet and Product Label before using. Take the necessary precautions dictated by the label to ensure that your health and that of your customers' is protected.



www.esteam.com

1-800-653-8338

See Material Safety Data Sheet at www.esteam.com/msds.php